

Overview

SOP users can create quality control readings and track them to an E-Ticket. Users with administrator, manager, foreman, plant, and the quality control roles can add new readings.

Create Reading

From the Load Details page, use the Quality Control panel to view and add QC readings.

To add a new QC record, enter the Temperature, select the Type (QC or VT), and select the Location (Plant or Roadway).

The QC Reading will be displayed in the panel and also on the E-Ticket. Users can delete their QC Reading and add a new one if needed.

QC records are linked to the user who created them. Users will see a name and call button for QC Readings created by other users, as well as a call button for the Plant Lab.

Quality Control Plant Lab

Time	Temp.	Details	User
11:39 pm	300.00	QC, Plant	Delete

Add Quality Control

Enter temperature

Select Type

Select Location

ADD QC